


FLUSH VALVE
47087-07 /47086-07

3156.015

82-2 Float Rod (not shown)


NO. 3 FLUSH VALVE

KEY No.	DESCRIPTION	PART No.	QTY
1	Unit "B"	8162	1
2	Unit "A"	—	1
3	Lift Chain S/A	8321	1
4	Actuating Unit	—	1
5	Screw	733-3	1
6	Nut	732-3	1
7	Screw	73382	1
8	Support Leg	722-2	1
9	Seat Disc	73383	1
10	Screw	737-2	2
11	Screw	729-2	3
12	Seat	—	1
13	Seal	—	1
14	Clamping Lug	—	3
15	Bolt Hole Seal	726-2	1
16	Lever	73439	1

IMPORTANT

THIS VALVE IS NOT A SUITABLE
REPLACEMENT IN ANY COMBINATION
IN WHICH OUTLET IS NOT IN CENTER OF TANK