



Buy it for looks. Buy it for life.®


■ Order by Part Number

There is more than 1 version of this model.
Page down to identify the version you have.

Illustrated Parts


PureTouch® Single Control Kitchen Faucet with Water Filter & Pullout Spray

MODEL	HANDLE TYPE	FINISH
DISCONTINUED SKUS		
7850	Lever	Chrome
7850S	Lever	Sand
7850W	Lever	Glacier



1/4 Turn Connector/
Screen Washer Kit
100444

Screen
Washer Kit
101199



Please Note: For under the deck parts, service kits, and valve bodies, you must refer to the following page.

• Note - Battery & Screw
Replacement Instructions: INS133A




Buy it for looks. Buy it for life.®

Illustrated Parts

■ Order by Part Number

PureTouch® Valve Bodies/Below Deck Parts

OLD STYLE VALVE BODY (Cast)–Prior to 1/99



NEW STYLE FABRICATED VALVE BODY (FVB)

