



KN-4

Replacement Valve Cartridge Instructions



Remove the old KN-4 cartridge with limit stop. Install the new KN-4 cartridge with limit stop.



Turn limit stop counterclockwise to allow full handle turn to the hot position. Turn limit stop clockwise to limit handle turn to the hot position.

Symmons Industries, Inc. 31 Brooks Drive, Braintree MA 02184
Tel: 1-800-SYMMONS, Fax: 1-800-961-9621, ZV-357 REV B 101217