


Faucet Service Kit Part List

1	Handle Button	N1201-16
2	Handle Screw	N1201-2H
3	Lock Washer	N1201-3
4	Handle	1103-9C
5	Centerpiece nut	1201-11C
6	Spout with spray	1103-7-8C
6a	Spout less spray	1101-7-8C
7	Diverter (spray model only)	1103-23
8	Aerator	50-19C
9	Bearing Washer	1101-7-3
10	Cartridge Kit	6-1201-5-0
11	Spout hub O-ring	1201-14-36
12	Shield	1102-12C
13	Bottom Plate	1102-15
14	Washer	1201-18
15	Nut	1201-11
16	Screw	1201-7-2
17	Side Spray ass'y	151-22-0

Cartridge Service Kit Part List

10.1	Ball Cap	N1201-4-5
10.2	Ball Lever	N1201-4-0
10.3	Ball Seat	N1201-4-2
10.4	O-ring	48-7-6
10.5	O-ring	42-5-6
10.6	Bonnet Bottom	
	for Metal body	1201-5-3
	for Plastic body	N1201-5-5
10.7	Seat Washer	N1201-5-2
10.8	Spring	1201-3-4
*10.9	Spring Insert	1201-3-1

* Spring insert not required with new service kits.